CDL^{Q&As}

Commercial Drivers License

Pass CDL CDL Exam with 100% Guarantee

Free Download Real Questions & Answers PDF and VCE file from:

https://www.lead4pass.com/cdl.html

100% Passing Guarantee 100% Money Back Assurance

Following Questions and Answers are all new published by CDL Official Exam Center

- Instant Download After Purchase
- 100% Money Back Guarantee
- 365 Days Free Update
- 800,000+ Satisfied Customers



https://www.lead4pass.com/cdl.html

2021 Latest lead4pass CDL PDF and VCE dumps Download

QUESTION 1

A. 150 psi			
B. 50 psi			
C. 45 psi			
D. 60 psi			

At what air pressure must the low air pressure warning signal come on?

The correct answer is: 60 psi. The warning light (or buzzer) must come on when the pressure falls below 60 psi.

QUESTION 2

Correct Answer: D

What two things are important to prevent rollover?

- A. Evenly loaded trailer and properly inflated tires
- B. Keeping the cargo as close to the ground as possible and drive slowly around turns
- C. The weight and length of the vehicle
- D. Keeping the cargo center of gravity as high as possible and drive slowly around turns

Correct Answer: B

QUESTION 3

When driving in very hot temperatures, you should:

- A. Check your tires every 2 hours or every 100 miles
- B. Let your tires cool down (remain stopped) if they are too hot to touch
- C. Insure that you have enough antifreeze in the system
- D. All of the above

Correct Answer: D

The correct answer is: All of the above. When driving in extreme heat it is important to check your tires every 2 hours or 100 miles. If the tires are too hot to touch, you should remain stopped until they cool off. You should also insure that you have enough antifreeze in the system.

https://www.lead4pass.com/cdl.html

2021 Latest lead4pass CDL PDF and VCE dumps Download

QUESTION 4

Pushing in the trailer air supply knob will do what?

- A. Supply air to the service air line
- B. Supply air to the emergency air line
- C. Shut off air to the trailer air tank
- D. Put on the emergency brakes

Correct Answer: B

The correct answer is: Supply air to the emergency air line. The trailer air supply control knob is used to control the tractor protection valve. You push the knob in to supply the trailer with air (via the emergency air line) and pull it out to shut off the air and put on the trailer emergency brakes.

QUESTION 5

The two-inch line on the floor behind the driver\\'s seat is known as

- A. Stand zone
- B. Driver area line
- C. Baggage line
- D. Standee line

Correct Answer: D

The correct answer is: Standee line. Riders are not allowed to stand forward of the rear of the driver\\'s seat. Buses that allow standing must have a "standee line" (two-inch line on the floor behind the driver\\'s seat) to show passengers where they cannot stand.

CDL PDF Dumps

CDL Exam Questions

CDL Braindumps



To Read the Whole Q&As, please purchase the Complete Version from Our website.

Try our product!

100% Guaranteed Success

100% Money Back Guarantee

365 Days Free Update

Instant Download After Purchase

24x7 Customer Support

Average 99.9% Success Rate

More than 800,000 Satisfied Customers Worldwide

Multi-Platform capabilities - Windows, Mac, Android, iPhone, iPod, iPad, Kindle

We provide exam PDF and VCE of Cisco, Microsoft, IBM, CompTIA, Oracle and other IT Certifications. You can view Vendor list of All Certification Exams offered:

https://www.lead4pass.com/allproducts

Need Help

Please provide as much detail as possible so we can best assist you. To update a previously submitted ticket:





Any charges made through this site will appear as Global Simulators Limited.

All trademarks are the property of their respective owners.

Copyright © lead4pass, All Rights Reserved.