

## DCPPE-200<sup>Q&As</sup>

Dell PowerEdge Professional Exam

**Pass Dell DCPPE-200 Exam with 100% Guarantee**

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.leads4pass.com/dcppe-200.html>

100% Passing Guarantee  
100% Money Back Assurance

Following Questions and Answers are all new published by Dell Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers



## QUESTION 1

A customer has five VRTXs in a chassis group that they need to disband. The engineer disbands the chassis group from the group leader, but a networking interruption prevents two of the VRTXs from getting the signal to leave the group.

What should the engineer do to finish disbanding the chassis group?

- A. Remove the remaining members from the group leader's Remove Members list
- B. Recreate the group from the group leader and disband it again
- C. Remove the group association from the group members individually
- D. Reboot the CMCs of the remaining members

Correct Answer: C

---

## QUESTION 2

An engineer is updating the IOM Infrastructure Device firmware from the CMC GUI. The IOMINF device is NOT listed as a device that can be updated.

What is causing this issue?

- A. IOMINF firmware is up to date.
- B. IOMINF firmware cannot be updated from CMC.
- C. The update can only be done using racadm commands.
- D. CMC firmware is not updated.

Correct Answer: A

---

## QUESTION 3

A new M1000e is being deployed in the data center. All initial power and data cabling is complete. The engineer checks the CMC Chassis Health and sees that one of the six PSUs displays as Failed (No AC).

An AC cable is connected, and the power distribution unit produces good AC output.

What two tasks should be completed to troubleshoot this issue? (Choose two.)

- A. Verify all PSUs are connected to the same voltage.
- B. Confirm System Input Power Cap is not set too low.
- C. Replace AC cable.
- D. Set AC redundancy to 4+1.

Correct Answer: AC

---

#### QUESTION 4

Only one of the server nodes in the FX2s chassis can see the FD332.

How should the chassis be configured so that both nodes can see the storage?

- A. Set storage mode to joined dual host
- B. Enable shared storage in the CMC
- C. Set storage mode to split dual host
- D. Enable clustering in the CMC

Correct Answer: C

---

#### QUESTION 5

An engineer has been given a new chassis and needs to configure the iDRACs on all servers prior to deploying an OS on them. The iDRACs need to be configured with IP addresses and a new root password.

What is the most efficient method to perform this task?

- A. Use CMC QuickDeploy
- B. Use iDRAC QuickLaunch
- C. Use CMC Server Profiles
- D. Use racadm quickdeploy

Correct Answer: D

[Latest DCPPE-200 Dumps](#)

[DCPPE-200 PDF Dumps](#)

[DCPPE-200 Braindumps](#)