

## E20-616<sup>Q&As</sup>

Symmetrix Installation and Troubleshooting Specialist

**Pass EMC E20-616 Exam with 100% Guarantee**

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.leads4pass.com/e20-616.html>

100% Passing Guarantee  
100% Money Back Assurance

Following Questions and Answers are all new published by EMC  
Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers



**QUESTION 1**

A CE is currently installing a VMAX 40K. Where should the light panel cables of the System Bay be connected?

- A. Engine 4
- B. 1st AC slot
- C. Engine 5
- D. 2nd AC slot

Correct Answer: A

---

**QUESTION 2**

What is the power level required for VMAX 20K Standard Storage Bay?

- A. 5.3 kVA
- B. 2.5 kVA
- C. 4.9 kVA
- D. 3.5 kVA

Correct Answer: A

---

**QUESTION 3**

Which SRDF/A feature prevents cache overflow on either the R1 or R2 devices?

- A. Write Pacing
- B. Transmit Idle
- C. SRDF Compression
- D. Delta Set Extension

Correct Answer: A

---

**QUESTION 4**

What is the vault hyper size in GB for configuring a new VMAX 40K?

- A. 9
- B. 5

C. 4.5

D. 0.5

Correct Answer: A

**QUESTION 5**

Refer to the exhibit.

Fibre Loops				DAEs							
ES	DA/DI	IOM	Port	0	1	2	3	4	5	6	
1	1/2	0	A0	S							
			A1	S	V	V					
			B0	S							
			B1	V	V	V					
		1	C0	S							
			C1	V	V	V					
			D0	S							
			D1	V	V	V					

What does '\\V\\' represent under the DAE Map Window of SymmWin?

- A. 25 disk drive DAE
- B. Surrogate
- C. 15 disk drive DAE
- D. Volume Set Addressing

Correct Answer: A

[E20-616 PDF Dumps](#)

[E20-616 Exam Questions](#)

[E20-616 Braindumps](#)