

HPE2-K42^{Q&As}

Designing HPE Nimble Solutions

Pass HP HPE2-K42 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.leads4pass.com/hpe2-k42.html>

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by HP Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers



QUESTION 1

Which tools can you use on a Windows host to connect to iSCSI volumes on an HPE Nimble array? (Choose two.)

- A. HPE Nimble Connection Wizard
- B. Microsoft iSCSI Initiator
- C. HPE Nimble Connection Manager
- D. HPE Nimble Windows Toolkit

Correct Answer: CD

Reference: <https://community.hpe.com/t5/HPE-Storage-Tech-Insiders/Nimble-OS-2-0-Part-2-Nimble-Connection-Manager-for-Windows/ba-p/6986545>

QUESTION 2

What are primary components of AF controller head shelf? (Choose three.)

- A. removable NVDIMM
- B. hard disk drives
- C. solid state disks
- D. dual power supplies
- E. dual controllers
- F. management controller

Correct Answer: CDE

Reference: NTS-2001-I_Nimble_Introduction_and_Admin.pdf

QUESTION 3

Which is included in HPE Nimble Windows Toolkit? (Choose two.)

- A. HPE Nimble VSS Writer
- B. HPE Nimble Connection Service (NCS)
- C. HPE Nimble VSS Requestor
- D. HPE NimbleInfo

Correct Answer: BC

QUESTION 4

How can controller failover be performed? (Choose two.)

- A. In CLI, use the command: failover.Perform it online via InfoSight.
- B. In WebUI, on the array level, click MAKE ACTIVE.
- C. In OCP, press the Failover button.
- D. Perform it online via InfoSight.

Correct Answer: AB

QUESTION 5

Following HPE best practices, when connecting a head unit to an expansion shelf, what port on the expansion shelf should you connect into?

- A. P4
- B. P1
- C. P3
- D. P2

Correct Answer: D

[HPE2-K42 PDF Dumps](#)

[HPE2-K42 VCE Dumps](#)

[HPE2-K42 Practice Test](#)